


SEVENNE XL / GRIFFON XL x 1



A2 x 1
B2 x 1
C x 7
D x 1




TV400 x 5



MZ140 x 6
MZ141 x 1
MZ142 x 1




MZ200 x 10
MZ260 x 6
MZ601 x 3
MZ602 x 4



P160 x 14
P220 x 12
P310 x 5

9212.013



ATTENTION: POUR CONTROLER CE VEHICULE, SE REPORTER AUX PRECONISATIONS DU CONSTRUCTEUR.
ATTENTION: TO CONTROL THE VEHICLE, REFER TO MANUFACTURER'S RECOMMENDATIONS.
ACHTUNG: ZUR ÜBERPRÜFUNG DES FAHRZEUGES, DIE HERSTELLERRICHTLINIEN BEACHTEN.
ATTENZIONE: PER IL CONTROLLO DEL VEICOLO, RIVOLGERSI ALLE RACCOMANDAZIONI DEL PRODUTTORE.
ATENCIÓN: AL CONTROL EL VEHICULO, CONSULTE LAS RECOMENDACIONES DEL FABRICANTE.




FIG.3




FIG.4




FIG.5




FIG.7





FIG.8




FIG.6




FIG.2

REP	REFERENCE	NB		NB
1	7295.5001	1	M12x1,50-140	4
2	7295.5002	1		
3	7295.5003	4		
4	7295.5004	1	M14-40	2
5	7295.5005	1		
8	7295.5008	1	LU8	2
9	7295.5009	1	M10	4
10	7295.5010	1	M12	4
11	7295.5011	1	M12-90	4
B.11.350	B.11.350	2	M8	2
VDC.002	VDC.002	2	TFHC M10-50	4
12	7295.5012	1	M12x1,50-70	2
13	7295.5013	1		
16	7295.5016	1		
17	7295.5017	1		
18	7295.5018	1	M12x1,50-40	2
19	7295.5019	1		
21	7295.5021	1		
BXY1	BXY1	1		
22	7295.5022	1	M8-55	2
23	7295.5023	1		
25	7295.5025	1		
BXY1	BXY1	1		
26	7295.5026	1	M8-70	2
27	7295.5027	1		
29	7295.5029	1	M8-40	2
30	7295.5030	1		
31	7295.5031	1	M14-70	2
32	7295.5032	1		
35	7295.5035	1	M10-30	4
36	7295.5036	1		
38	7295.5038	1	M14-70	2
39	7295.5039	1		
42	7295.5042	2		
43	7295.5043	1	M10	2
44	7295.5044	1	M14	2
			M14-40	2
45	7295.5045	1	M8	2
46	7295.5046	1	M8-50	2
47	7295.5047	1	M6-30	2






FIG.1







SEVENNE XL / GRIFFON XL x 1




A2 x 1
B2 x 1
C x 5
D x 1




TV400 x 5




MZ080 x 10




MZ140 x 4




MZ200 x 2



MZ260 x 2




MZ601 x 1




MZ602 x 2



P100 x 10



P220 x 6
















P310 x 5




9212.013





ATTENTION: POUR CONTROLER CE VEHICULE, SE REPORTER AUX PRECONISATIONS DU CONSTRUCTEUR.
ATTENTION: TO CONTROL THE VEHICLE, REFER TO MANUFACTURER'S RECOMMENDATIONS.
ACHTUNG: ZUR ÜBERPRÜFUNG DES FAHRZEUGES, DIE HERSTELLERRICHTLINIEN BEACHTEN.
ATTENZIONE: PER IL CONTROLLO DEL VEICOLO, RIVOLGERSI ALLE RACCOMANDAZIONI DEL PRODUTTORE.
ATENCIÓN: AL CONTROL EL VEHICULO, CONSULTE LAS RECOMENDACIONES DEL FABRICANTE.



REP	REFERENCE	NB		NB
1	7295.5001	1		
2	7295.5002	1		
4	7295.5004	1	M14-40	2
5	7295.5005	1		
6	7295.5006	2		
7	7295.5007	2		
12	7295.5012	1	M12x1,50-70	2
13	7295.5013	1		
14	7295.5014	2		
15	7295.5015	2		
* 18	7295.5018	1	M12x1,50-40	2
19	7295.5019	1		
20	7295.5020	2		
* 22	7295.5022	1	M8-55	2
23	7295.5023	1		
24	7295.5024	2		
* 26	7295.5026	1	M8-50	2
27	7295.5027	1		
28	7295.5028	2		
31	7295.5031	1	M14-50	4
32	7295.5032	1		
33	7295.5033	2		
34	7295.5034	2		
38	7295.5038	1	M14-70	2
39	7295.5039	1		
40	7295.5040	2		
41	7295.5041	2		
43	7295.5043	1	M10	2
44	7295.5044	1	M14	2
			M14-40	2
45	7295.5045	1	M8	2
46	7295.5046	1	M8-50	2
47	7295.5047	1	M6-30	2






1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51

SEVENNE XL / GRIFFON XL x 1



A2 x 1
B2 x 1




TV400 x 2



MZ260 x 4



P160 x 2
P220 x 2



9212.013



ATTENTION: POUR CONTROLER CE VEHICULE, SE REPORTER AUX PRECONISATIONS DU CONSTRUCTEUR.
ATTENTION: TO CONTROL THE VEHICLE, REFER TO MANUFACTURER'S RECOMMENDATIONS.
ACHTUNG: ZUR ÜBERPRÜFUNG DES FAHRZEUGES, DIE HERSTELLERRICHTLINIEN BEACHTEN.
ATTENZIONE: PER IL CONTROLLO DEL VEICOLO, RIVOLGERSI ALLE RACCOMANDAZIONI DEL PRODUTTORE.
ATENCION: AL CONTROL EL VEHICULO, CONSULTE LAS RECOMENDACIONES DEL FABRICANTE.

CONTROLE BERCEAU DEPOSE
KONTROLLE DES INTEGRALTRÄGER
CHECKING WITHOUT CRADLE IN PLACE
CONTROLLO SENZA TELAIO
CONTROL DEL BASTIDOR DESMONTADO

